American Coding and Marking Ink Co.



1220 NORTH AVENUE PLAINFIELD, NJ 07062

Phone: 908-756-0373 Fax: 908-756-0570 Web Site: www.americancoding.com Email:customer@trecoder.com

TRECODER® Backpack Directions

- 1.) Fasten suction tube to TRECODER® gallon container.
- 2.) Hold Spot Gun even with or above the level of the gallon.
- 3.) Start pumping Spot Gun to fill and prime the systems. This will take about 30 40 strokes. If air bubbles develop while priming, hold Spot Gun above gallon container until air clears out of the system.
- 4.) Once the system is primed, put backpack on. Prime will remain as long as there is ink in the gallon container.
- 5.) Should prime be broken, repeat the above. Some reasons for loss of prime are: empty container, leak in hose connections, worn O-rings.
- 6.) For complete operating and maintenance instructions, refer to TRECODER® Spot Gun operating and maintenance sheet.

FORESTRY PRODUCTS DIVISION